










Specification

| Model | Size(unit:mm) | Voltage | Current | Holding Force | Lock Signal | Door Signal | Time | Door |
|------------------|------------------|--------------------------------------|------------------------------------|-------------------|-------------|-------------|-------------|-------------|
| YM-350N | 260Lx54.7Wx29.6H | DC12V(Default); DC24V(Adjustable) | 12V/500mA±10% 24V/250mA±10% | 350kg(800Lbs) | NO | NO | No | Single Door |
| YM-350 | 260Lx54.7Wx29.6H | DC12V(Default); DC24V(Adjustable) | 12V/500mA±10% 24V/250mA±10% | 350kg(800Lbs) | NO/NC/COM | NO | No | Single Door |
| YM-350NT(LED) | 260Lx54.7Wx29.6H | DC12V(Default); DC24V(Adjustable) | 12V/500mA±10% 24V/250mA±10% | 350kg(800Lbs) | NO/NC/COM | NO | 0/3/6/9sec. | Single Door |
| YM-350N(LED)-DS | 260Lx54.7Wx29.6H | DC12V(Default); DC24V(Adjustable) | 12V/500mA±10% 24V/250mA±10% | 350kg(800Lbs) | NO/NC/COM | NO/NC/COM | No | Single Door |
| YM-350ND | 520Lx54.7Wx29.6H | DC12V(Default); DC24V(Adjustable) | 12V/500mA±10%x2 24V/250mA±10%x2 | 350kgx2(800Lbsx2) | NO | NO | No | Double Door |
| YM-350ND(LED) | 520Lx54.7Wx29.6H | DC12V(Default); DC24V(Adjustable) | 12V/500mA±10%x2 24V/250mA±10%x2 | 350kgx2(800Lbsx2) | NO/NC/COM | NO | No | Double Door |
| YM-350NTD(LED) | 520Lx54.7Wx29.6H | DC12V(Default); DC24V(Adjustable) | 12V/500mA±10%x2 24V/250mA±10%x2 | 350kgx2(800Lbsx2) | NO/NC/COM | NO | 0/3/6/9sec. | Double Door |
| YM-350ND(LED)-DS | 520Lx54.7Wx29.6H | DC12V(Default); DC24V(Adjustable) | 12V/500mA±10%x2 24V/250mA±10%x2 | 350kgx2(800Lbsx2) | NO/NC/COM | NO/NC/COM | No | Double Door |


Diagram(unit:mm)









Fold the plate to 90° .




Close the door first, then place the upper side of template on door frame, while adjust the left side next to the door leaf.




Mark screw positions of armature plate and magnetic lock on door leaf and door frame respectively.




Drill holes based on the marked positions.




Make a combination based on the picture.



Strike the pin into the armature plate slightly (to avoid movement).




Make a combination based on the picture (add washer accordingly). The rubber ring must be added.



Place the rubber ring between armature plate and door leaf.




Use Allen key to remove the mounting plate from lock body.



Fix the mounting plate on the door frame according to the holes drilled earlier.




Use Allen key to screw the lock body on the mounting plate.




Close the door to test holding force. The angle between armature plate and magnetic lock can be adjusted by adding or reducing washers.




After all the appropriate procedures, the holding force can be maximized. Finally, fix the tamper screw.



Drill a hole Inside: Diameter is 8mm Outside: Diameter is16mm



Drill a hole Inside: Diameter is 8mm Outside: Diameter is 12.7mm



Inside:Drill a hole diameter is 8mm folding the plastic straight pin

A Notice:

Thickness of Door Leaf:

350LBS: 44mm 600LBS: 50mm 800LBS: 48mm 1200LBS: 46mm

A. The screw of armature plate should not be fixed too tight. Proper elasticity should be guaranteed for

the rubber ring so that the armature plate can adjust itself to the appropriate position. B. Check the jumper's position before connecting. Figure out it represents 12VDC or 24VDC.

Different brackets are available according to different types of doors. For example, narrow door, frameless glass door and inward opening door.


L Bracket

When the door frame thickness is less than 42mm, L bracket is needed.





Single Door Magnetic Lock Bracket





Double Door Magnetic Lock Bracket

LC Bracket

LC Bracket one-piece design, wires are mortised, no damage on wires










Single Door Magnetic Lock Bracket

If install a bracket on inward opening door, ZL bracket is needed





Single Door Magnetic Lock Bracket





ZLC Bracket

Hidden-line Design of bracket for single door magnetic lock, one-piece design, durable, easy installation










Double Door Magnetic Lock Bracket

Attention: No GZ bracket for 500kgs series available currently.

GZ Bracket

One-piece design, durable & professional design, easy installation, suitable for 10-15 mm frameless glass door






Single Door Magnetic Lock Bracket



Double Door Magnetic Lock Bracket

If door leaf is glass,need U bracket to be used with lock (suitable for 10-12mm glass door) $\,$





Single Door Magnetic Lock Bracket

Installation of Armature Plate

If door leaf is too thick, need to choose I bracket





Double Door Magnetic Lock Bracket

Circuit Board Diagram


A.12VDC Input:

Connect the positive(+)lead from a 12VDC power source to V +.

Connect the ground(-)lead from a 12VDC power source to V -.

Check jumper for 12 VDC operation.

Wiring Instruction of Single Door Magnetic Lock



B.24VDC Input:

source to V+.

source to V -.


Connect the positive(+)lead from a 24VDC power

Connect the ground(-)lead from a 24VDC power


Check jumper for 24 VDC operation.

Wiring Instruction of Double Door Magnetic Lock

Connection: green wire or white plug, except the models without LED indicator and signal output; only when it detects that double doors have been locked, there will be normal signal output.



Wire Connection



www.yli.cn We create security